


#### STRA9 90 TSL

Sear engagement	19	Ejector pin	36
plunger spring		Hammer spring	32
Safety lever	99	gnide	
plunger		Hammer spring	34
Safety lever	99	тэттен	33
Trigger plunger spring	<b>†</b> 9	Bolt lock spring	35
Trigger plunger		Bolt lock lever	31
	63	Buij	
Trigger pin	29	Bolt lock lock	30
Trigger	19	Bolt lock pin	57
Disconnector pin	09	uid	
Disconnector	69	Hammer-stop	28
niq gningz	-	Hammer pin	27
Пізсоппестог	28	Safety lever pin	97
spring		Satety	52
Disconnector	78	Satety lever	77
Sear pin	99	uid	,,
2631	22	Safety plunger	23
rielease latch pin	4.0	Safety plunger	22
anizagaM	75	SCLEW	50.5
release latch	23	Safety-lock	SI
release button	C3	SCLGW	
Magazine	25	Front-tang	20
Release spring		SCLGM	
Magazine	19	Rear-tang	61
Fing		Trigger guard	81
plate, pin, lock	00	Rear sight	17
Selector lever	09	Front sight	91
Selector lever plate pin	6Þ	Barrel	12
lock ring, large	ΟV	Operating handle	TT
Selector stud	84	Recoil spring	13
Selector stud	LV	guide	
lock ring, small	2.	Recoil spring	12
Selector stud	95	Firing pin	11
Selector lever	97	Extractor	OI
piate		plunger	L.
Selector lever	לל	Extractor spring	6
niq		Extractor spring	8
Selector lever	43	Operating handle	,
plate spring			7
Selector lever,	ZÞ	Bolt	9
(5 or 10 shots)	Y.	Buings nig gninia	ç
Magazine	It	Firing pin- niq gninister	Þ
Wension seriew	04	Receiver Firing nin-	E
Trigger & selector housing	38	niq lerred	Z
Ejector	38	Take-down pin	250
			Ţ
SIMAY YO ICL			

67 Sear engagement screw


37 Elector pin 36 Ejector pin

WEATHERBY MARK XXII



Canadian Sauer, Ltd., 103 Church St. • Toronto, 2781 E. Firestone Blvd. • South Gate, Calif.





YOUR WEATHERBY MARK XXII is the finest production sporting .22 rimfire rifle made today. We have used the same precision techniques in its manufacture that we use for the Mark V big game magnums. The finest steels and alloys, selected stock wood, and close attention to details combine to give you a .22 built to last a lifetime.

### UNTER

The safety (see A, Fig. 1) is located conveniently on top of the tang where it may be reached with the thumb. To engage safety, pull back, exposing the "S." To release safety, push forward, covering the "S."

### LOADING

Use only .22 long rifle ammunition. Regular or high speed. CAUTION: Before loading, make sure the bore is free of grease or obstructions! Put rifle on "SAFE." Place Shot Selector (C) on "AUTO" position. Remove magazine by pressing button (G) to the rear of the magazine. Load magazine (H) and insert it into position. Pull back operating handle (D) and release. Safety must now be released before rifle can be fired.

### CNLOADING:

Put rifle on "SAFE." Remove magazine. Put shot selector on "SS" position and pull back operating handle to extract cartridge from chamber. For maximum safety, leave bolt in opened position. (The MARK XXII is one of the few .22 LR autoloading rifles with this automatic feature.)

#### TRIZO

The Single Shot Selector (C) located just behind the operating handle on the right side can be set in two positions. To fire your MARK XXII as a regular semi-automatic (one shot for each pull of the trigger until the magazine is empty with no other operations necessary) place the Selector on "AUTO." The fired cases will be ejected and the bolt will close automatically. However, the bolt will stay open when the rifle is empty.

To fire your MARK XXII as a single shot rifle, place the Selector on "SS." After every shot the bolt will stay open. In order to release the bolt it will be necessary to push the Selector forward and this operation will close the bolt and chamber the next cartridge from the magazine. This is a valuable feature when teaching youngsters shooting and when on the range where safety is especially emphasized. The conscious effort required to close the bolt after each shot encourages deliberate thinking and actions... important in safety training.


#### SOLLIS

Your MARK XXII is grooved for a telescopic sight (E). Follow scope manufacturer's recommendations' for installation.

There are three folding leaf sight settings on your MARK XXII (F): 50, 75 and 100 yards. Invariably the 50-yard setting is the one most used. Practice in range estimation will help you greatly in making the most of the other two settings. Your Mark XXII was sighted using high-speed ammunition. With any .22 LR rimfire rifle a scope is recommended beyond 75 yards.

## DISASSEMBLY:

BE SURE RIFLE IS UNLOADED! Remove takedown pin (B) at rear of receiver by pushing from right to left. With one hand, press forward on receiver, at the same time carefully lift barrel with the other hand. (Fig. 2) The barrel and receiver assembly will lift out of the stock. The underside of the bolt and receiver recess may be cleaned as well as the hammer and selector assemblies. NO FURTHER DISASSEMBLY IS NECESSARY OR RECOMMENDED. Disassembly of the hammer, trigger and selector assemblies should only be performed by a competent gunsmith or our factory.



### ASSEMBLY:

Carefully place barrel and receiver in stock and slide rearward until the holes in the receiver line up. Insert takedown pin at the left side of rear of receiver and press in.

# CARE AND CLEANING:

As all auto-loading firearms are more sensitive to malfunctions caused by accumulations of dirt and powder fouling than manually operated firearms, it is important that your MARK XXII be kept clean.

# TO CLEAN BORE:

BE SURE RIFLE IS UNLOADED! Pull back operating handle and leave bolt open. Insert cleaning rod from muzzle and use bristle brush or cloth patch saturated with powder solvent; follow with dry patch and lightly oiled patch.

# TO CLEAN BOLT:

Clean face of bolt with brush or cloth saturated with powder solvent followed by dry cloth, then slightly oiled cloth. DO NOT USE EXCESSIVE OIL! Wipe exterior of metal parts with lightly oiled cloth or silicone cloth. Wipe stock with silicone cloth.

### WARRANTY

Your Weatherby MARK XXII rifle is a precision firearm manufactured of the finest materials and has been thoroughly inspected and tested in every phase of production. Attached to your rifle is your Weatherby Warranty. Be sure it is filled in and returned to the factory.